


UniFoilPrinter Flat Bed Lock Removal


PELEMAN®

- Ⓔ REMOVE BEFORE USE
- Ⓕ ENLEVER AVANT L'USAGE
- Ⓖ VOR GEBRAUCH ENTFERNEN
- Ⓔ REMOVER ANTES USO
- Ⓘ TOGLIERE PRIMA DELL USO
- Ⓖ VERWIJDEREN VOOR GEBRUIK
- Ⓔ УДАЛИТЬ ПЕРЕД ПОДКЛЮЧЕНИЕМ
- Ⓒ 使用前取下
- Ⓐ لامعتس الال لبق لزا



Please use the screwdriver included in the packaging.

To order article: **SPUP000011**



Reattach the locking tool and screws as shown in the picture to avoid losing them.

UniFoilPrinter Flat Bed USB drive

PELEMAN®

Use the included UniFoilPrinter USB drive to:

- install the UniFoilPrinter software & drivers
- consult the UniFoilPrinter Manual
- see *how-to* videos



UniFoilPrinter USB driver

To order article: **SPUP0000144**